

mDynamo and DynaWave

Update and Test Baud Rate - Remote Services v2.0 Installation and Operation Guide



January 7, 2021

Document Number: D998200351-20

REGISTERED TO ISO 9001:2015

Copyright © 2006 - 2021 MagTek, Inc. Printed in the United States of America

INFORMATION IN THIS PUBLICATION IS SUBJECT TO CHANGE WITHOUT NOTICE AND MAY CONTAIN TECHNICAL INACCURACIES OR GRAPHICAL DISCREPANCIES. CHANGES OR IMPROVEMENTS MADE TO THIS PRODUCT WILL BE UPDATED IN THE NEXT PUBLICATION RELEASE. NO PART OF THIS DOCUMENT MAY BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, FOR ANY PURPOSE, WITHOUT THE EXPRESS WRITTEN PERMISSION OF MAGTEK, INC.

MagTek® is a registered trademark of MagTek, Inc. MagnePrint® is a registered trademark of MagTek, Inc. Magensa[™] is a trademark of MagTek, Inc. MagneSafe® is a registered trademark of MagTek, Inc DynaPro[™] and DynaPro Mini[™], are trademarks of MagTek, Inc. ExpressCard 2000[™] is a trademark of MagTek, Inc. IPAD® is a trademark of MagTek, Inc. IntelliStripe® is a registered trademark of MagTek, Inc.

Google Play[™] store, Google Wallet[™] payment service, and Android[™] platform are trademarks of Google Inc.

Apple Pay®, iPhone®, iPod®, Mac®, and OS X® are registered trademarks of Apple Inc., registered in the U.S. and other countries. iPad[™] is a trademark of Apple. Inc. App StoreSM is a service mark of Apple Inc., registered in the U.S. and other countries. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used by Apple Inc. under license.

Microsoft®, Windows®, and .NET® are registered trademarks of Microsoft Corporation.

All other system names and product names are the property of their respective owners.

Rev Number	Date	Notes
10	Nov 13, 2019	Initial Release
11	Dec 29, 2020	Corrected Magtek Reader Config App Hyperlink and
12	Jan 7, 2021	Update template to MagTek

Table 0-1 - Revisions

SOFTWARE LICENSE AGREEMENT

IMPORTANT: YOU SHOULD CAREFULLY READ ALL THE TERMS, CONDITIONS AND RESTRICTIONS OF THIS LICENSE AGREEMENT BEFORE INSTALLING THE SOFTWARE PACKAGE. YOUR INSTALLATION OF THE SOFTWARE PACKAGE PRESUMES YOUR ACCEPTANCE OF THE TERMS, CONDITIONS, AND RESTRICTIONS CONTAINED IN THIS AGREEMENT. IF YOU DO NOT AGREE WITH THESE TERMS, CONDITIONS, AND RESTRICTIONS, PROMPTLY RETURN THE SOFTWARE PACKAGE AND ASSOCIATED DOCUMENTATION TO THE ADDRESS ON THE FRONT PAGE OF THIS DOCUMENT, ATTENTION: CUSTOMER SUPPORT.

TERMS, CONDITIONS, AND RESTRICTIONS

MagTek, Incorporated (the "Licensor") owns and has the right to distribute the described software and documentation, collectively referred to as the "Software."

LICENSE: Licensor grants you (the "Licensee") the right to use the Software in conjunction with MagTek products. LICENSEE MAY NOT COPY, MODIFY, OR TRANSFER THE SOFTWARE IN WHOLE OR IN PART EXCEPT AS EXPRESSLY PROVIDED IN THIS AGREEMENT. Licensee may not decompile, disassemble, or in any other manner attempt to reverse engineer the Software. Licensee shall not tamper with, bypass, or alter any security features of the software or attempt to do so.

TRANSFER: Licensee may not transfer the Software or license to the Software to another party without the prior written authorization of the Licensor. If Licensee transfers the Software without authorization, all rights granted under this Agreement are automatically terminated.

COPYRIGHT: The Software is copyrighted. Licensee may not copy the Software except for archival purposes or to load for execution purposes. All other copies of the Software are in violation of this Agreement.

TERM: This Agreement is in effect as long as Licensee continues the use of the Software. The Licensor also reserves the right to terminate this Agreement if Licensee fails to comply with any of the terms, conditions, or restrictions contained herein. Should Licensor terminate this Agreement due to Licensee's failure to comply, Licensee agrees to return the Software to Licensor. Receipt of returned Software by the Licensor shall mark the termination.

LIMITED WARRANTY: Licensor warrants to the Licensee that the disk(s) or other media on which the Software is recorded are free from defects in material or workmanship under normal use.

THE SOFTWARE IS PROVIDED AS IS. LICENSOR MAKES NO OTHER WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Because of the diversity of conditions and PC hardware under which the Software may be used, Licensor does not warrant that the Software will meet Licensee specifications or that the operation of the Software will be uninterrupted or free of errors.

IN NO EVENT WILL LICENSOR BE LIABLE FOR ANY DAMAGES, INCLUDING ANY LOST PROFITS, LOST SAVINGS, OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE, OR INABILITY TO USE, THE SOFTWARE. Licensee's sole remedy in the event of a defect in material or workmanship is expressly limited to replacement of the Software disk(s) if applicable.

mDynamo and DynaWave | Update and Test Baud Rate - Remote Services v2.0 | Installation and Operation Guide

GOVERNING LAW: If any provision of this Agreement is found to be unlawful, void, or unenforceable, that provision shall be removed from consideration under this Agreement and will not affect the enforceability of any of the remaining provisions. This Agreement shall be governed by the laws of the State of California and shall inure to the benefit of MagTek, Incorporated, its successors or assigns.

ACKNOWLEDGMENT: LICENSEE ACKNOWLEDGES THAT HE HAS READ THIS AGREEMENT, UNDERSTANDS ALL OF ITS TERMS, CONDITIONS, AND RESTRICTIONS, AND AGREES TO BE BOUND BY THEM. LICENSEE ALSO AGREES THAT THIS AGREEMENT SUPERSEDES ANY AND ALL VERBAL AND WRITTEN COMMUNICATIONS BETWEEN LICENSOR AND LICENSEE OR THEIR ASSIGNS RELATING TO THE SUBJECT MATTER OF THIS AGREEMENT.

QUESTIONS REGARDING THIS AGREEMENT SHOULD BE ADDRESSED IN WRITING TO MAGTEK, INCORPORATED, ATTENTION: CUSTOMER SUPPORT, AT THE ADDRESS LISTED IN THIS DOCUMENT, OR E-MAILED TO SUPPORT@MAGTEK.COM.

Table of Contents

SOF	TWARE LICENSE AGREEMENT	3
Tab	le of Contents	5
1	The purpose of this document	6
2	Connect to MagTek Reader Configuration App	6
3	Disconnect from the MagTek Reader Configuration App	7
4	Connect to OEM Demo App	8

1 The purpose of this document

These instructions explain how to change the Baud Rate for mDynamo using the Windows version of the MagTek Reader Configuration App (RS2/Remote Services). It will also explain how to test the DynaWave after properly configuring the baud rates for both devices.

2 Connect to MagTek Reader Configuration App

Download the MagTek Reader Configuration App

Launch the MagTek Reader Configuration App.

Connect mDynamo via USB.

Once the device is detected, it will show its device details in the upper right corner.

File Edit Option Help Device List: 0900 ProductID:1A Refresh Reset Serial Number: B4D639A103119AA Interface Type: 0 - HID Security Level: 03 Dukpt ReaderID: 1A Reader Configuration Send Commands EMU ReaderID: 1A Firmware: 000003358F01 Scial Number: Serial Number: Scial Number: B4D639A103119AA Interface Type: 00 Scial Number: B4D639A00006 Scial Number: B4D639A00006 Change Key DUKPT KSN: Firmware: eDynamo Firmware Loaded Script:	Magree Reader Configuration - DEV			
Device List: 0900 ProductID:1A Petect ReaderID: 1A Primware: 100003358F01 Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Level: 03 Change Configuration Send Commands EMV Reader Config Options: ReaderID: 1A Firmware: 1000003358F01 Serial Number: B4D639A103119AA Interface Type: 00 Change Config Serial Number: B4D639A103119AA Interface Type: 0 Meret Change Config Serial Number: B4D639A103119AA Interface Type: 0 Key: 3C 9013380 O O HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006 O HID Security Level: 03 DukPT KSN: 901380 O HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006 Run Script Run Script Run Script Number: A A A Run Script Run Script Number: A A A A Run Script Run Script <td>File Edit Option Help</td> <td></td> <td></td> <td></td>	File Edit Option Help			
Refresh Reset Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Levei: 03 DUKPT KSN: 9011880B4D639A000006	Device List: 0900 ProductID:1A	900 ProductID:1A Detect ReaderID: 1A Firmware: 1000003358F01		ReaderID: 1A Firmware: 1000003358F01
Clear DUKPT KSN: 9011880B4D639A000006 Change Configuration EMV Reader Config Options: ReaderID: 1A ImDynamo UART 115200 Firmware: 1000003358F01 Change Config Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006 DUKPT KSN: 9011840 Key: OL Change Key DUKPT KSN: 9011880B4D639A000006 Firmware: eDynamo Firmware Loaded Script: Run Script		Refresh	Reset	Serial Number: B4D639A103119AA Interface Type: 00 - HID
Change Configuration Bend Commands EMV Reader Config Options: ImDynamo UART 115200 Immware: 1000003358F01 Change Config Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Level: 03 DUKPT KSN: 901188084D639A000006 DUKPT KSN: 901188084D639A000006 Firmware: eDynamo Firmware-1000003354 • Loaded Script: Immodel firmware Run Script Immodel firmware			Clear	DUKPT KSN: 9011880B4D639A000006
Reader Config Options: ImDynamo UART 115200 Firmware: 1000003358F01 Change Config Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006 DUKPT KSN: 9011880B4D639A000006 Sc 9013380 • Download Firmware eDynamo Firmware: eDynamo Firmware Engle Key Run Script • •	Change Configuration Send Commands EMV			
	Reader Config Options: mDynamo UART 115200 Change Config Key: 3C 9013380 Change Key Firmware: eDynamo Firmware-1000003354 • Download Firmware Loaded Script: Run Script	ReaderID: 1A Firmware: 1000003358F01 Serial Number: B4D639A10311 Interface Type: 00 - HID Security Level: 03 DUKPT KSN: 9011880B4D639/	9AA 4000006	~

mDynamo and DynaWave | Update and Test Baud Rate - Remote Services v2.0 | Installation and Operation Guide

Select mDynamo UART 115200 in the drop down for Reader Config Options. Make sure the Key is set to "Current Key". Press the Change Config button.

File Edit Option Help Device List: 0900 ProductID:1A Perform Perform Refresh Secial Number: B4D639A103119AA Interface Type: 00 - HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006 DUKPT KSN: 9011880B4D639A000006 Change Config Pendeerline: 1A Firmware: Pirmware: 1000003358F01 Security Level: 03 DUKPT KSN: 9011880B4D639A000006 Security Level: 03 DUKPT KSN: 9011880B4D639A000006 MAGENSA PROD UIK 9014501 • Change Key Firmware: eDynamo Firmware Loaded Script: Download Firmware Iterace Run Script	MagTek Reader Configuration - DEV		
Device List: 0900 ProductID: 1A Petect Reader1D: 1A Firmware: Bead Commonds EMV Change Config Bend Commands EMV Readerl Config Options: ReaderlD: 1A mDynamo UART 11520 ReaderlD: 1A Change Config Firmware: 1000003358F01 Serial Number: B4D639A000006 Serial Number: B4D639A000006 Serial Number: B4D639A103119AA Interface Type: 00 Change Config Serial Number: Key: Readerl Contig MAGENSA PROD UIK 901450t • DUKPT KSN: 9011880B4D639A000006 Firmware: BDynamo Firmware Loaded Script: Download Firmware Image: Run Script	File Edit Option Help		
Refresh Reset Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006 Change Configuration Send Commands EMV Reader Config Options: mDynamo UART 115200 Change Config Key: Change Config Key: Change Config ReaderID: 1A Firmware: Change Config Key: MAGENSA PROD UIK 901450t • Firmware: eDynamo Firmware Loaded Script: Image Config Run Script Run Script	Device List: 0900 ProductID:1A	oductID:1A Detect ReaderID: 1A Firmware: 1000003358F01	
Clear DUKPT KSN: 9011880B4D639A000006 Change Config Options: ReaderID: 1A [mDynamo UART 115200 Serial Number: B4D639A103119AA [nterface Type: 00 - HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006 Security Level: 03 Dukpt KSN: 9011800F4D639A103119AA Interface Type: 00 - HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006 Firmware: Dukpt KSN: 9011880B4D639A000006 Loaded Script:	Refresh	Reset	Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Level, 02
Change Configuration Send Commands EMV Reader Config Options: mDynamo UART 115200 Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Level: 03 Duminoad Key Change Key Firmware: eDynamo Firmware eDynamo Firmware Download Firmware Loaded Script:		Clear	DUKPT KSN: 9011880B4D639A000006
Reader Config Options: ReaderID: 1A ImDynamo UART 115200 Firmware: 1000003358F01 Change Config Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006 Security Level: 03 DUKPT KSN: 9011800H2639A000006 Security Level: 03 Duker KSN: 9011880B4D639A000006 Security Level: 03 Immark: Buker KSN: 9011880B4D639A000006 Security Level: 03 Security Level: 03 Duker KSN: 9011880B4D639A000006 Security Level: 03 Immark: Buker KSN: 9011880B4D639A000006 Security Level: 03 Security Level: 03 Download Firmware Buker KSN: 9011880B4D639A000006 Run Script Run Script	Change Configuration Send Commands EMV		
	Reader Config Options: Reader ID: 1A ImDynamo UART 115200 Serial Number: B4D639A10 Interface Type: 00 - HID Serial Number: B4D639A10 Key: Interface Type: 00 - HID MAGENSA PROD UIK 901450(+) Security Level: 03 Change Key DukPT KSN: 9011880B4D6 Firmware: EDynamo Firmware-1000003354 + Download Firmware Loaded Script: Run Script Run Script	3119AA 339A000006	· · · · · · · · · · · · · · · · · · ·

When complete, the main dialog box will indicate that the Configuration was "Successfully Changed".

magree header configuration - DEV				
File Edit Option Help				
Device List: 0900 ProductID:1A	Refresh	Detect Reset Clear	ReaderID: 1A Firmware: 1000003358F01 Serial Number: B4D639A103119AA Interface Type: 00 - HID Security Level: 03 DUKPT KSN: 9011880B4D639A000006	
Change Configuration Send Commands EMV Reader Config Options: mDynamo UART 115200 • Change Config Key: Default Magensa Key 9011880 • Change Key Firmware: eDynamo Firmware-1000003354 • Download Firmware Loaded Script: Run Script	Getting KSN 9011880B4D639/ Getting Configuration Name m Changing Configuration To: Cha Successfully Changed -> Chan	A000007 Dynamo UART ange mDynam ige mDynamo	115200 10 UART to 115200 UART to 115200	*

3 Disconnect from the MagTek Reader Configuration App.

Disconnect from the MagTek Reader Configuration App. Please power cycle the mDynamo.

mDynamo and DynaWave | Update and Test Baud Rate - Remote Services v2.0 | Installation and Operation Guide

4 Connect to OEM Demo App

Download the <u>MTSCRA OEM Demo App</u> Launch the MTSCRA OEM Demo App. Connect mDynamo via USB and select NFC module in the UART Port drop-down list.

•
EMV: Start Cancel Timeout 60 •
Transaction Type Contactless Card
Response: Approved 🔻 Options: 🔳 Quick Chip
EMV Terminal: Get Config Set Config Commit
Command:
Send Command Set Time> UART 🔻
Type: USB 🔻 ID: 0900 🔹 Scan
SPI Port: None 🔻 UART Port: NFC Module 💌
*₩ Connect X₩ Disconnect 🗲 Clear

Press the Connect button.

🗊 MTSCRA OEM Demo	-
[Sending Command] 000168 [Device Response] 000101	
[Sending Command] 491E0000030C00180000000000000000000000000000	
EMV: Start Cancel Timeout: 60 🔻	
Transaction Type Contactless Card	
Response: Approved 🔹 Options: 📃 Quick Chip	
EMV Terminal: Get Config Set Config Commit	
Command:	
Send Command Set Time> UART 🔹	
Type: USB 👻 ID: 0900 💌 Scan	
SPI Port: None 👻 UART Port: NFC Module 👻	
[◆] Connect 같 Clear 같 Clear	





mDynamo and DynaWave| Update and Test Baud Rate - Remote Services v2.0 | Installation and Operation Guide

mDynamo and DynaWave| Update and Test Baud Rate - Remote Services v2.0 | Installation and Operation Guide

TSCRA OEM Demo	x
Command:	
0400002600C0050020491E0000030C001800000000000000 0000000000000000000	00
[Device Extended Response]	
[Device Extended Response]	
[UART] [UART NFC - Device Response]	E
[UART] 0A060000000000	-
EMV: Start Cancel Timeout: 60	•
Transaction Type Contactless Card	
Response: Approved	
EMV Terminal: Get Config Set Config Commi	t
Command:	
Send Command Set Time> UART	
Type: USB 🔻 ID: 0900 🔫	Scan
SPI Port: None 🔻 UART Port: NFC Module 🔻	
Tre Connect Clea	ir

Select Contactless Card in the Transaction Type drop-down list.

Press the Start button to begin an EMV transaction.

"Present Card" will appear in the main dialog box at the top of the screen.

MISCRA OEM Demo	
PRESENT CA	KD.
[UAKI] [UAKI NFC - Device Kesponse]	A
[Device Extended Response]	
0400002C00C002000D00050000030000050	400010000C0C00200
14000C00000301000C50524553454E54204	3415244C0
[UART] [Transaction Status]	
[UART] 0400010000	
[UART] [Display Message Request]	E
[UART] PRESENT CARD	
EMV: Start Cancel	Timeout: 60 🔻
Transaction Type Contactless Card	•
Response: Approved Options:	Quick Chip
EMV Terminal: Get Config Set Con	fig Commit
Command:	
Send Command Set Time	> UART 🔻
Type: USB 🔻 ID: 0900	▼ Scan
SPI Port: None 🔻 UART Port:	NFC Module 👻
+₩ Connect ×₩ Disconnect	≽ Clear

mDynamo and DynaWave | Update and Test Baud Rate - Remote Services v2.0 | Installation and Operation Guide

Hold a Contactless EMV Card or NFC token/phone near the DynaWave.

After the data is acquired and transmitted to the app via the DynaWave, a message will be appear in the main dialog box at the top of the screen.

MTSCRA OEM Demo
APPROVED
3030303030303030303030303030303030303 [UART] 00=
[UART] 00= [Device Response]
0000 [Device Extended Response]
0400001300C002000D00050000030000050600130000C0 [UART] [Transaction Status]
[UART] 0600130000
EMV: Start Cancel Timeout: 60 •
Transaction Type Contactless Card 🔹
Response: Approved 🔹 Options: 🔲 Quick Chip
EMV Terminal: Get Config Set Config Commit
Command:
Send Command Set Time> UART 🔻
Type: USB 🔻 ID: 0900 🔻 Scan
SPI Port: None VART Port: NFC Module V
♥₩ Connect 같 Clear