

IntelliStripe 380 (Motorized IntelliCoder) Transition to Win 7 32 Bit

For devices purchased after January 2008



May require switching from MCP Mode (aka Standard Mode) to ASCII Mode

> PN 99875632 Rev 1.01 January 2014

MagTek® Inc., 1710 Apollo Court, Seal Beach, CA 90740 | p 562-546-6400 | support 651-415-6800. | f 562-546-6301 | www.magtek.com Registered to ISO 9001:2008 © Copyright 2013 MagTek, Inc

For IntelliStripe 380 Devices purchased after January 1, 2008

IN FIELD UPDATE: Customers can update IntelliStripe 380 devices in the field using the following set of instructions.

Log into the Win 7 32 bit PC as an Administrator with full rights.

Scenario #1 - Currently Installed Workstation

If the IntelliStripe 380 Motorized IntelliCoder has been installed and working on a Win 7 32 bit machine it may require switching from MCP Mode (aka Standard Mode) to ASCII Mode. Log into the PC as an Administrator and follow Steps 1 through 7 below. Run MCP and the MCP Protocol Switching Protocol by right clicking on both applications and click on Run As Administrator. (Note: If UAC is on, hold down the shift key and right click on the applications executable and click on Run As a Different User. Enter credentials and continue with installation).

Scenario #2 - New PC Workstation Installation

Prior to using the MCP Switching Protocol program, first, the MCP Driver must be installed in the Standard Mode, as an Administrator, on the PC. Once completed, restart the PC as prompted. Log back in as an Administrator. Connect the IntelliStripe 380 (also referred to as the Motorized IntelliCoder) to the PC. Once the device driver and hardware have been configured and are ready to use, open Device Manager, Ports, and check to see the port assignment that has been established for the IntelliStripe 380. Configure MCP by adding the device name, i.e. IntelliStripe 380, select the correct com port, click OK and Close. Then, follow Steps 1 through 7 below.

Device can be switched from "Standard Mode" to "ASCII Mode" using the following instructions and the Protocol Switching Program (PN 99510016).

Continued...

Step 1

Run the MCP Configuration Utility (as a user with Admin rights) – Leave MCP OPEN (DO NOT CLOSE UNTIL THE SWITCH IS COMPLETED)

es: Intrelistripe sourc	D9D3	<u> </u>	Add	
eneral race File Path:				
:\Windows\MCPTrac	:e.log			
ransport Specific Port	DavidDeter	Deribu	Charla	
ransport Specific Port Name: COM4	BaudRate: 9600 💌	Parity: Even	Stopbits:	•

Step 2

Note the specific COM Port and Device Name used by the encoder. In this example we are using IntelliStripe 380 USB and COM4

		🗆 Transport Speci	fic
		Port	
Devices:	IntelliStripe 380 USB	COM4	•
			100

Step 3

Open the MCP Protocol Switch Utility (as a user with Admin rights)

Status	
Detect Current Mode	Switch Modes
Select both the Device Instance Na Select Device Instance N IntelliStripe 380 USB	me and Serial Port Name About

Step 4

CLICK on the Device Instance Name (it will then be highlighted in Blue) and select the Serial Port noted from the MCP Configuration Utility and press the "Detect Current Mode" button. After detection, the button to the right (Switch Modes) will become enabled and will change its description to "Change to ASCII"

Step 5

Press the button "Change to ASCII"

The Status will indicate that it successfully changed to ASCII mode. (You will also hear the motor turn off and on during the switching process).

Step 6

Press the Close Button

Step 7

Navigate back to the MCP Configuration Utility and change the Protocol selection to 'ASCII' and Press OK